

Seattle - Spokane - Salt Lake - San Diego

Garage Door Terminology

Standard industry terminology:

The members of DASMA have compiled an extensive list of terms and definitions related to the sectional garage door industry. www.DASMA.com

The terminology information encompasses many common terms used in the sectional garage door industry. You will note that some terms are cross-referenced to a "primary" term. The "primary" term is the one that would be used most often in DASMA standards and technical publications. This Technical Data Sheet includes a compilation of commonly used terms, and may not be considered complete from an industry viewpoint.

The terms and definitions are not universal. Variations within the industry may exist with regard to precise meaning.

3-Hole Adjustable Clip: See 3-Hole Cable Clip

3-Hole Cable Clip: Metal clip tied to end of extension spring cable to allow length adjustment

3-Hole Cable Connector: See 3-Hole Cable Clip

Accent Moulding: Half-round and square moulding that provide a distinctive mode of expression to

doors

Access Door: See Pass Door

Active Coils: The number of working coils in a torsion spring

Adjustable Cone: See Winding Plug Adjustable Sleeve: See Winding Plug Adjusting Rod: See Winding Rod

Adjusting Spring Cone: See Winding Plug **Aero Cable:** See Aircraft-Type Cable

A-Frame: Support member used to fasten torsion spring assembly of a vertical lift door to the wall

above the door opening

Air Infiltration: The leakage or passage of air through a door system

Aircraft Cable: See Aircraft-Type Cable

Aircraft-Type Cable: Several strands of galvanized wire rope braided together

Anchor Cone: See Stationary Cone **Anchor Plug:** See Stationary Cone

Angle Brace: Lateral brace attached to back hang and roof construction or ceiling

Angle Iron: Length of L-shaped steel material generally used to support and brace rear of horizontal

tracks from roof construction or ceiling

Angle Mounted Track: A method of fastening vertical track to a door jamb using a full height

continuous angle

Anodize: A hard non-corrosive oxide film on the surface of aluminum

Astragal: See Bottom Weatherseal 8/1/01 rev. 12/12 Page 3 of 28 This sheet is reviewed periodically and may be

Astragal Floor Rail: See Bottom Weatherseal **Astragal Retainer:** See Bottom Weatherseal

Automatic Latch: An automatic door locking device

 $\underline{www.GarageDoorSeattle.com} \quad \underline{www.GarageDoorSaltLake.com} \quad \underline{www.GarageDoorSpokane.com} \quad \underline{www.GarageDoorSanDiego.net} \quad \underline{www.GarageDoorSpokane.com} \quad \underline{www.GarageDoorSonDiego.net} \quad \underline{www.GarageDoorSpokane.com} \quad \underline{www.GarageDoorSonDiego.net} \quad$



Seattle - Spokane - Salt Lake - San Diego

Automatic Opening Device: Quick opening mechanism recommended for installations requiring rapid automatic door opening without use of an

electric operator

Back Hang: Hanger fabricated from angle iron, which attaches the end of the horizontal tracks to roof construction or ceiling

Back Jamb: Wood member on the inside surface of the garage, surrounding the door opening **Backroom:** Horizontal distance measured into a building from the face of the header above a garage door opening to the first obstruction at the required headroom

Ball Bearing: A load bearing device that uses trapped rolling balls to reduce rotating friction **Ball Bearing Drum:** Counterbalance drum with a ball bearing for smoother operation of heavier doors

Bar Joist: A lightweight truss adaptable for the support of roof decks

Bead: A strip of metal, vinyl, or rubber used to secure glass around the periphery of a pane

Black: Color-marking convention to mark parts as Right Side, Left Wound

Blind Rivet: A type of fastener that mechanically joins two pieces of material together by means of a riveting tool

Booster Spring: Additional spring, usually an extension spring, provided to compensate for weakened counterbalance

Bottom Bracket: A structural support located predominantly on the bottom section that holds track rollers and may also provide for attachment of lifting cables. Bracket locations other than at bottom section corners are possible.

Bottom Corner Bracket: See Bottom Bracket **Bottom Corner Fixture:** See Bottom Bracket

Bottom Fixture: See Bottom Bracket

Bottom Rail: The lower-most horizontal rail of a door section

Bottom Roller Bracket: See Bottom Bracket

Bottom Weatherseal: Weatherstrip attached to the bottom rail of a door to seal against the floor **Bow:** Condition where a garage door bottom rail of a wood door is not level or straight, which is

characterized by a closed door "smiling" (corners turned up)

Box Strut: See Strut

Bracket Mounted: Method of fastening vertical track to jamb using angle brackets

Bracket-Mounted Track: See Bracket Mounted **Breakaway Track:** See Angle Mounted Track

Breakstem Rivet: See Pop Rivet

Broken Cable Device: A bottom fixture intended to prevent a door from falling in the event of cable

breakage

Buck: See Back Jamb

Bushing: A fixed or removable lining used to constrain, guide, or reduce friction

Cable: See Aircraft-Type Cable

Cable Clamp: Manufactured device used to secure two pieces of cable to each other

Cable Drum: Grooved drum, fitted on torsion spring shaft, onto which lifting cable is wound when

door is opened



Seattle - Spokane - Salt Lake - San Diego

Cable Drum Set Screws: Normally refer to set screws that attach the drum to the shaft/tube. One screw may secure the cable to the drum in order to

secure proper cable length.

Cable Length: Specific amount of cable required to properly operate door

Cable Safety Device: A bottom fixture designed to slow or stop the descent of a door in the event of

a cable breakage

Cable Stop: A swaged fitting at the end of the cable to prevent slippage through a slot in a drum

Cable Stopping Device: See Broken Cable Device

Cam: Rotating piece that transfers rotary motion into linear motion

Cam Tube: Tube encasing a torsion spring assembly that imparts axial force

Carry-Away Post: A type of removable center post **Ceiling:** Top horizontal surface in the interior of a garage

Center Bearing Bracket: A bracket that houses a shaft bearing and aligns and supports the torsion

shaft and spring(s) assembly. Also serves to anchor stationary cone(s) to header

Center Bearing Plate: A plate or bracket that can house a shaft bearing and is used to align and support the counterbalancing mechanism to the torsion shaft as well as anchor one end of torsion

springs to the header.

Center Bearing Support: See Center Bearing Bracket

Center Bracket: See Center Bearing Plate

Center Bushing: Metal or plastic bushing used with a center bracket to support a torsion tube

Center Cable: See Center Lift Cable **Center Clamp:** See Center Lift Cable

Center Coupler: See Coupler Center Coupling: See Coupler

Center Hinge: A hinge generally located on the intermediate stiles to allow sections to pivot as door

opens. Also used as graduated edge hinge between bottom and intermediate section

Center Lift Cable: Additional cable assembly which is secured to outside of door at points toward the center of the door, used to provide extra lifting support for extremely wide or heavy doors.

Center Post: The vertical building structure (or member) between two single car doors, or a vertical reinforcement usually installed for high wind events. Sometimes also used to refer to a Vertical Post.

Center Stile: Vertical member of a door section which provides structural rigidity and location for center hinge attachment

Center Support Bearing: See Center Bearing Bracket

Center Support Track: See Center Track

Center Track: Added track giving additional support to preventing sagging of a door in the open or horizontal position. Often used with an exceptionally wide door, a heavy door or a door containing a pass door

Chain Hoist: Refers to sprocket or pocket wheel, connected to torsion spring shaft, imparting

mechanical advantage to open and close a door

Chain Hoist Operator: Jackshaft type operator to which chain hoist is attached



Seattle - Spokane - Salt Lake - San Diego

Channel Frame: Frame used in jamb construction consisting of steel channel shapes installed where the flanges of the shapes wrap around the corners of

jambs

Channel Truss: See Strut

Chill: A square shaft that connects an outside handle to an inside lock set or night latch

Clearance: The amount of side room, head room and back room required to properly install a

sectional door.

Clear Rail: See Solid Rail **Clevis:** See Sheave Fork

Clevis Pin: A steel pin used in conjunction with a cotter pin to hold a counterbalance cable to a

bottom bracket or an operator arm to an operator bracket

Commercial: A sectional overhead type door which is intended for vehicular use at entrances of buildings such as loading docks and service stations, and is normally operated less than 5,000 cycles

per year

Containment Cable: A cable threaded through an extension spring to retain the spring if it breaks

Continuous Angle: See Reverse Angle Mount

Continuous Angle Mount: See Angle Mounted Track

Contour Track: Horizontal track that follows the contour of roof construction or ceiling

Corner Bracket: See Bottom Bracket

Corner Burn: A full-scale fire test performed in a specially constructed room, where the ignition

source is located in the corner of that room, adjacent to the garage door

Cotter Pin: A half-round metal strip bent into a pin, whose ends can be flared after insertion

through a slot or hole

Counterbalance: To oppose or balance with an equal weight or force

Counterbalance Shaft: See Torsion Shaft

Counterbalance System: A system which counteracts the weight of a garage door to allow a

reduced force to open and close the door **Counterbalance Tension:** See Counterbalance

Counterweight: Design of door mechanisms using weights instead of springs to counterbalance

door weight

Counterweight Balancing System: See Counterweight

Coupler: A device to connect two counterbalance shafts together, end-to-end

Coupling: See Coupler "C" Strut: See Strut

C-Value: Heat rate flow through an insulating material when there is a temperature difference from

outer to inner surfaces; not normally used in conjunction with thermal transmittance through

garage doors

Cycle: One complete cycle of a door beginning with the door in the closed position, then moving to

the open position and back to the closed position

Cylinder: The part of a key operated lock that accepts the key and contains the locking pins

Daylight Opening: Opening dimensions taken between face of jambs and between floor and header

DC: Door opening size designation, denoting "double car"



Seattle - Spokane - Salt Lake - San Diego

Dead Coils: The number of coils rendered inactive by the spring plugs **Dead-End Cone:** See Stationary Cone

Dead in the Head: The lack of counterbalancing when the door is in the open position, failing to keep the door fully open

Dead Load: A static applied load, or a load without movement, generally referring to the weight of the door

Decal: A template of information attached to a garage door, or in its vicinity, to convey relevant information concerning the garage door system

Decorator Angle: See Jamb Angle

Depth: See Backroom

Design Wind Load: Horizontal design load applied to a garage door based on such factors as wind

speed, building height and door horizontal location

Direct Drive Chain Hoist: See Chain Hoist

Disconnect Chain: Used in conjunction with industrial door operators to disengage operator and permit manual use of emergency hand chain to facilitate operation of door in event of power failure

Disconnect Hoist: See Disconnect Chain

Door Casing: The framing members with which a door opening is finished

Door Check: A mechanical device to insure the self closing of a pass door or wicket **Door Closer:** A device, combining in one case, a spring to close the door, and a checking

arrangement to prevent slamming and to insure silent closing

Door Frame: The frame into which the door fits; consists of two door jambs, and a door header

Door Framework: See Door Frame

Door Guide: See Track

Door Header: The upper part of a door frame, consisting of the head jamb, head casing, stop and

trim molding

Door Jamb: The upright framing on each side of the door opening

Door Moulding: See Door Casing **Door Opener:** See Electric Operator **Door Opening:** See Daylight Opening **Door Operator:** See Electric Operator

Door Path: See Trajectory

Door Schedule: A list of door sizes, locations and special requirements shown on a construction

document

Door Section: A single segment of a sectional door

Door Size: Door dimensions characterized by the width first and the height second

Door Stop: See Stop Mould **Door Travel:** See Trajectory

D Shaft: A torsion shaft manufactured with a flat area allowing minimum rotation of affixed

hardware.

Double Door: Commonly used to refer to larger width doors used on two car openings

Double End Stile: When a door section utilizes two stiles adjacent to each other on each end of the

section



Seattle - Spokane - Salt Lake - San Diego

Double Glazing: Use of two thicknesses of glazing within an opening to improve insulating value and/or reduce sound transmission

Double Low Headroom Track: See Double Track Low Headroom

Double Shaft: Double torsion spring shaft used when additional space is required to accommodate counterbalance spring lengths

Double Strength Glass: A grade of window glass lighter than plate glass and usually 1/8" thick

Double Thick Glass: See Double Strength Glass

Double Top Roller Fixture: Fixture used at the top section consisting of two top brackets to

incorporate a longer roller shaft. Usually requires double end stiles on top section

Double Track Low Headroom: Addition of second pair of horizontal tracks to reduce the high point of travel of top section and permit door being mounted in area with minimum headroom facilities **Dowel:** Wooden pin for fastening wood usually glued in between stiles and rails to strengthen a joint

Drawbar Operator: Electric operator which mounts above the door in the horizontal position and lifts door by pulling and pushing the top section. For normal headroom and low headroom doors **Drip Cap:** A projection over the head of a door opening, or on the top of a wall, to throw water clear

of the building

Drip Lap: An angled weather seal provided between sections on steel doors in lieu of a rabbeted joint to prevent entrance of the elements

Driveway Post: Post mounted adjacent to a residential driveway to provide exterior location for key switch to actuate an automatic door operator.

Drop-Off Weight: See Counterweight

DSB: Acronym for Double Strength Grade B Glass

Duplex Spring: A combination of two torsion springs of different diameters telescoped within spring

fittings

Eased Edge: Rounded and sanded meeting rail edge

Eased Off: See Eased Edge

Eave Height: Height measured from the floor to the underside of an eave

Edge Grain: Wood in which the rings form an angle of 45 degrees or more with the surface of the

pieces

Edge Hinge: See Graduated Edge Hinge **Electric Opener:** See Electric Operator

Electric Operator: An electrically-powered device to control the opening and closing of a door **Electrical Interlock:** Interlock to prevent door operation by an electric operator under certain

conditions

Embossed Door Section: Door section featuring embossed panels

Embossed Panel: Panel containing surfaces raised in relief from a flat surface

Embossed Rosette: Special ornament or design accessory made of wood, hardboard or aluminum

with designs raised in relief from the surface **Embossed Section:** See Embossed Door Section

Embossed Steel Door Section: See Embossed Door Section



Seattle - Spokane - Salt Lake - San Diego

End Bearing Plate: Plate commonly used on torsion spring counterbalance units, which includes a ball bearing to support radial movement of a torsion

shaft at each end

End Bearing Support: See End Bearing Plate

End Bracket: See End Bearing Plate
End Hinge: See Graduated Edge Hinge
End Roller Hinge: See Graduated Edge Hinge

End Stile: Stile located at each end of a door section which provides for attachment of graduated

edge hinges

End Stile Lock: See Inside Lock

End Stile Sealing Strip: Foamed plastic strip to seal sections at end stiles of steel and fiberglass

doors

Escutcheon: A plate surrounding the lock mechanism on outside of door

Exhaust Port: Opening in bottom section to accept hose to vent tailpipe exhaust

Extension Spring: Provides power or tension by stretching or pulling, and is usually mounted along

the horizontal section of track extending from front of door opening to the back hang

Exterior Lock: Keyed lock on exterior of the door

Extrusion: Fabricated shapes made by forcing hot aluminum, or plastic, billets through a die in an

extrusion press

False Louver Molding: Special angular shaped molding that gives an appearance of a slatted panel

when fitted together

Faux Divided Lite: One piece of glass divided by muntons to appear as several lites.

Ferrule: Metal ring or cap which is affixed to a cable by compressing so as to form a button or loop

on the end of the cable

Finger Joint: Joint used in joining lumber together at ends of lumber pieces

Finish Moulding: See Stop Mould

Finished Door Opening: See Daylight Opening Finished Opening: See Daylight Opening

Fire Station Release: See Automatic Opening Device

Flag: See Jamb Angle

Flag Angle: See Jamb Angle Flag Bracket: See Jamb Angle

Flame Spread Index: A measurement of horizontal flame spread across a product specimen under controlled laboratory conditions; the product is compared to the performances of red oak, which is

standardized to 100, and gypsum board, which is standardized to zero

Flipper: See Automatic Latch

Floor Seal: See Bottom Weatherseal

Floor Step: See Rain Stop Flush Design: See Flush Door

Flush Door: Door comprised of sections unbroken by visible rails and stiles where the facing of the

entire door presents an even surface

Follow Roof-Line Hardware: See Contour Track



Seattle - Spokane - Salt Lake - San Diego

Follow-the-Roof Pitch: See Contour Track Follow-the-Roof Track: See Contour Track

Front Mounted Low Headroom: Low headroom hardware where springs mount on torsion shaft

above opening

Front-Mounted Spring: A counterbalance spring that is mounted to the header above the door

Full Vertical Lift: See Vertical Lift

Full View Section, Full Vision Section (A totally glazed section with various types of glass or clear plastic. Section formed of aluminum extrusions which will marry with steel or aluminum sections

above and below)

Full Vision Section: See Full View Section

Galvanizing: Zinc coating to protect steel against corrosion

Garage Door Opener: See Operator **Garage Door Operator:** See Operator

Gauge: U.S. Standard, established by congress in 1893, specifying that weight per square foot would be indicated by a numbering system; larger numbers indicate smaller thicknesses and vice versa

Glazed: Fitted with panes of glass or clear plastic

Glazing Lite: See Vision Lite

Glazing Strip: Extruded plastic or rubber strips that fit against glazing and window frame to resist

water infiltration

Graduated Edge Hinge: Hinge placed on edge of door sections allowing sections to pivot as door opens and closes. Hinges hold track roller and are graduated and numbered for correct placement

to ensure flush fit of door against jambs when closed **Grease Packet:** Lubricant enclosed in a small packet

Grille: Insert within a window, designed to give the appearance of divided lites

Guard Angle: See Track Guard

Gusset: Cast, extruded, stamped, or rolled aluminum corner reinforcement which is fastened in

corners to stiffen joints or corners

Gusset Plate: Hardware fastened to door header to help support the track assembly and spring

assembly

Hang Down: The amount of the door that hangs down from the door opening when the door is in

the open position

Hanging Iron: See Angle Iron

H-Column Jamb: Separation of two door openings where door track is to be mounted directly to H-

Column

Header: See Door Header **Header Seal:** See Top Seal

Headplate: The supporting plate for the lifting drum located in line with the outer edge of the door

Headroom: Vertical clear space required inside above the door opening, and below the lowest

ceiling obstruction, required for proper operation of the door and its hardware **Heliarc Weld:** A type of inert gas-shielded arc welding employing helium or argon

High Arc: See Trajectory



Seattle - Spokane - Salt Lake - San Diego

High Cycle Spring: Counterbalance springs with increased cycle life capability for high usage doors

High Lift: Distance from header to underside of horizontal track, when high lift track is required

High Lift Drum: A cable drum contoured to balance a high lift door

High Lift Track: Track and hardware that causes the door to rise vertically some distance above the

top of the door opening before it levels out into a horizontal position

High Moment Arm: Radius of a cable drum, including cable, at point of cable peel off from the drum

High Trajectory: See Trajectory

Hi-Lift: See High Lift

Hi-Lift Track: See High Lift Track

Hinge: Hardware item that joins door sections together, and allows sections to pivot independent

of each other

Hinge Support Plate: Plate used to support the hinge mounting area, i.e. a backup plate

Hinge Tube: Tube used to connect two hinge leafs together

Hoist Electric Operator: Similar to a jackshaft-type operator but with an auxiliary emergency chain

hoist in case of a power failure

Horizontal Angle: See Horizontal Track Angle

Horizontal Radius: Section of track that transitions from vertical to horizontal track welded, bolted

or riveted to the horizontal track and then bolted to the flag angle

Horizontal Reinforcing Angle: See Horizontal Track Angle

Horizontal Rise: The upward slope of the horizontal track which helps to start the door downward

and helps maintain cable tension

Horizontal Track: Track used in the horizontal segment of a track assembly

Horizontal Track Angle: An "L" shaped angle affixed to the horizontal track to stiffen it

Horizontal Track Assembly: An assembly made up of horizontal track and reinforced with an angle

that is used to both guide and support the door in the horizontal position

Horizontal Track Radius: See Horizontal Radius

Hot Off The Floor: Condition where the door has a tendency to lift off the floor

Inch-Pounds: English unit of measurement of torque

Inclined Track: Tapered spacing of the vertical track away from the jamb, permitting weather tight

closing of door against jamb and easy release for opening door by eliminating friction

Inside Hook Up: Connection where the counterbalance cable is on the inside of the track, between

the door sections and the vertical track

Inside Hook Up Bottom Bracket: Bottom bracket where the cable is routed between the vertical

track and the door sections

Inside Lock: Spring loaded, sliding deadbolt lock or spring latch operable only from interior of the

door

Installation: Placing a door in position for use

Installer: Person placing the door in position for use

Insulated Door: Door sections containing insulating material

Insulating Glass: Multi-pane glass assembly containing air space between panes for insulation

Insulation: Material having ability to reduce heat or cold transmission



Seattle - Spokane - Salt Lake - San Diego

Interior Lock: See Inside Lock

Intermediate Hinge: See Center Hinge

IPPT: Acronyn for Inch-Pounds Per Turn; torque rate of a spring, indicating the number of inch-

pounds of torque delivered to a shaft for each turn the spring is wound

ISLO: Acronym for "inside looking out"

Jackshaft-Type Operator: Operator which is mounted on wall or ceiling, with drive provided to turn

a torsion shaft

Jamb: See Door Jamb

Jamb Angle: See Angle Mounted Track

Jamb Bracket: "L" shaped bracket used to connect the vertical track to the door jamb

Jamb Extension: Framing extensions of door jambs above opening height; required to support door

track and spring assemblies

Jamb Guard: See Track Guard

Jamb Seal: See Stop Mould

Joint, Rabbeted: See Joint Shiplap

Joint, Shiplap: A raised back portion of a section joint, fitting with a lowered front portion of a

section joint, to create a weather tight seal between door sections

Joint, Tongue-and-Groove: A joint with an interior raised portion, fitting with a joint with an interior

lowered portion, to create a weather tight seal between door sections

Joint Bracket: See Splice Jamb Bracket

Joint Seal: See Section Joint Meeting Rail Seal

Keeper Plate: See Striker Plate

Key: A square piece of steel that slides into a key way to prevent parts from rotating on a shaft

Key Alike: See Keyed-Alike

Key Switch Control: Use of key switch to actuate a door operator in place of or in addition to a

push-button or transmitter

Key Way: A groove, milled into an object, which when used with a key will prevent parts from

rotating on a shaft

Keyed-Alike: Two or more lock cylinders intended to be opened with the same key

Keyed Shaft: A shaft that has an integrated key way

K-Value: Laboratory-determined value of thermal conductance of a material

"L" Strut: See Strut

Lag Screw: A heavy wood screw with a square or hex head and a coarse thread **Lap Jamb:** Condition where door sections lap the door opening on each jamb

Lapped Joint: See Joint, Shiplap **Latch Lock:** See Automatic Latch

Lateral Force: Force applied from or toward the side

Lift Bracket: See Bottom Bracket **Lift Clearance:** See High Lift

Lift Clearance Track: See High Lift Track

Lift Handle: Handle for manually operating a sectional door

Lift Plate: See Step/Lift Plate



Seattle - Spokane - Salt Lake - San Diego

Lintel: Beam provided over an opening to carry wall and/or roof loads over an opening

Lite: See Vision Lite

Lock: Device to secure door to vertical track(s) in the closed position

Lock Bar with Cremone: Rotating the cremone or lock bar disc from outside or inside will force lock

bars into cut-outs in track to lock door

Lock-On Bottom Roller Bracket: See Bottom Bracket

Lock Strike: See Striker Plate

Long-Stem Roller: Roller with a shaft length of 7 inches or longer

Louver: An opening with slats or screening for ventilation

Low Headroom Hardware: See Low Lift Hardware

Low Lift Hardware: Low headroom accessories which enable a door system to operate in minimal

headroom conditions

Low Moment Arm: Smallest radius, or distance from the shaft axis, to the center of the cable that

regards cable peel off point on cable drums LSLO: Acronym for left side looking out Lubricant: A substance used to lubricate

Lubricate: To make a surface smooth or slippery; to reduce friction

Maintenance: The act of keeping a door system in good working condition

Master Keyed: See Master Keying

Master Keying: Arrangement whereby cylinder locks, although fitted with different keyed cylinders,

can be opened or locked by means of one master key

Meeting Rail: The top horizontal rail or bottom horizontal rail of any section that meets and joins to

form a weatherproof seal

Metallurgist Report: A report or document that describes the composition of a metal

Mill Certification: A report or document from the producing mill that provides all pertinent data

relative to the composition, structure, heat, etc. of a given metal

Minimum Headroom: See Headroom Minimum Sideroom: See Sideroom

MIP: Acronym for Maximum Inch-Pounds; (IPPT x Turns = MIP); Used to describe the total torque required on a shaft to raise a given door weight from the floor, and also is the measurement of the torque capacity of a particular wire size at a desired cycle level of operation

Modular Coordination: The dimensioning of building units so that they will fit together, and the use of building dimensions consistent with such coordinated sizes.

Mounting Plate: Flat steel or wood member placed on the wall to accommodate spring supports, spring shaft bearings, chain hoists and mounting for operators

Movable Post: Post designed to allow the use of two or more doors in a single opening with carryaway aluminum center posts that can be removed when doors are in up position.

Mullion, Garage Door: A vertical post used as a door reinforcement

Mullion, Window: Framing member forming a divide between units of a window **Muntin:** A bar member supporting and separating panes of glass within a sash or door

Munton, Window: Munton that defines a faux divided lite.

Mutt: See Stile



Seattle - Spokane - Salt Lake - San Diego

Neoprene: A synthetic rubber made by polymerizing chloroprene **Nicopress Sleeve:** A two-hole aluminum or copper sleeve through which

cable is passed. Swaging will upset the sleeve to form a loop at cable end

Normal Headroom: See Headroom

Normal Sideroom: See Sideroom

Numbered Hinge: See Graduated Edge Hinge

Numbered Panel: Area between stiles I.S.L.O. numbered left to right

Numbered Roller Bracket: See Graduated Edge Hinge

Numbered Section: See Door Section **Nylon Center Bearing:** See Bushing

Oil: See Lubricant

Oil-Canning: A slight buckling in sheet metal, causing the appearance of waviness or unevenness

Opener: See Operator

Opening Height: Distance from floor to the bottom of header

Opening Size: See Daylight Opening

Opening Width: Distance between jambs of the door opening

Operator: Electric device used to control the up and down motion of the door

Outside Hook Up: Connection where the counterbalance cable is on the outside of the tracks **Outside Hook-Up Bottom Bracket:** Bottom bracket where the cable is routed outside the tracks

Outside Pull: See Outside Hook Up

Overlay: Decorative ornaments of metal, wood or hardboard used for outside decoration of garage

door sections

Pan Door: A garage door composed of sheet metal door sections

Panel: A raised and decorative design on door sections

Pass Door: A swinging pedestrian door built into a sectional door. Not recognized as an exit door by

model codes

Pedestrian Door: Access door adjacent to upward acting doors. Used as a legal means of egress to

avoid the use of a sectional door

Perforated Angle: Angled metal with a serried of punched holes used to hang garage doors and

operators

Perimeter Seal: Weatherstrip installed at the perimeter of a garage door

Pinch Resistant: Term for a door that has been designed to prevent entrapping, crushing, breaking,

severing or dislocating a person's finger

Plastic Muntin: See Muntin

Pocket Wheel: A wheel or drum machined to receive the individual links of a chain; used to directly

transmit power

Polyurethane: A type of foam insulation commonly foamed in place by manufacturers of garage

door sections

Pop Rivet: See Blind Rivet

Pounds Pull: Unit of force determined by dividing the torque by the moment arm of the drum **Power Unit:** A complete torsion spring assembly consisting of springs, shaft, winding plugs and

stationary cones, drums and cables



Seattle - Spokane - Salt Lake - San Diego

Pre-Finished: Finish characterized by galvanized steel painted with a primer,

then given an oven-baked top coat

Pre-Painted: See Pre-Finished

Prime: To lay on the first coat of primer paint **Prime-Painted:** Coated with primer paint

Pull Down Rope: A rope connected to the bottom bracket; used to manually pull the door down

Pull Rope: See Pull Down Rope

Pull Type Spring: See Extension Spring

Pulley: A wheel turning around an axis and having a groove on its rim in which runs a cable, chain,

or rope

Pulley Clevis: See Sheave Fork
Punched Angle: See Angle Iron

Punched Angle Brace: See Angle Brace
Punched Angle Iron: See Angle Iron

Punched Angle Track Hanger: See Back Hang

Purlin: A horizontal roof member spanning between beams and trusses to which roofing is

attached; commonly used in a pre-engineered, industrial type building

Push Down Spring: Spring-activated push rods mounted on horizontal tracks to start door down during closing portion of door cycle; generally used with a jackshaft-type operator or a manual

chain hoist

Pusher Bumper: A leaf spring in place of a rod

Push Nut: Stamped metal fastener designed to be pushed onto a shaft to secure an assembly

Quarter Grain: See Edge Grain

Quarter Round: Molding showing a quarter circle in its cross section

Quarter Turn: A unit of turn measurement when winding tension into a torsion spring

Quick Turn Bracket: See Low Lift Hardware

Radial Force: A force generated from the center of an object toward the outside

Radius: See Horizontal Radius Radius Track: See Horizontal Radius Rail: Horizontal member of a section

Rain Ledge: See Rain Stop

Rain Stop: Ledge provided at the point where the bottom rail meets the floor to prevent water from running under the door and allowing for runoff of the water onto the drive or approach

Raised Panel: See Panel

Rate of Rise: Measurement of change per revolution of a drum's moment arm

Rear Mount: When the counterbalance system attached to the rear of the horizontal tracks

Rear-Mounted Torsion: See Rear Mount **Rear Track Hanger:** See Back Hang

Red: Indicates color for Left Side, Right Wound **Regular Angle Mount:** See Angle Mounted Track



Seattle - Spokane - Salt Lake - San Diego

Removable Center Post: Post/track assembly which substitutes for door jamb in wide door openings so that multiple doors may be used instead of a

single large door, and which can be released and carried from an opening

Removable Jamb Wall: Wall designed to allow the use of two or more doors in a single opening with carry-away aluminum center posts that can be removed when doors are in up position

Removable Mullion: See Removable Center Post Removable Post: See Removable Center Post

Residential: A sectional overhead type door which is intended for use in a residential garage, and

normally operated less than 1,500 cycles per year

Restraining Cable: See Containment Cable

Return: See Sideroom

Reverse Angle: See Reverse Angle Mount

Reverse Angle Mount: An "L" shaped angle with the wall leg toward the door opening used to connect the vertical track to the jamb. Used in low headroom and sideroom restricted garages as well as lap joint.

Roll-Away Post: See Removable Center Post

Roller: See Track Roller

Roller Assembly: See Track Roller

Roller Bracket: A device that is mounted to a door section and holds a track roller

Roller Stem: See Track Roller Rounded Off: See Eased Edge

RSLO: Acronym for "right side looking out"

R-Value: Thermal resistance value; inverse of U-Value **Safety Bottom Bracket:** See Broken Cable Device

Safety Bottom Corner Bracket: See Broken Cable Device

Safety Bottom Fixture: See Broken Cable Device

Safety Cable: See Containment Cable

Safety Spring Containment: See Containment Cable **Safety Spring Containment Kit:** See Containment Cable

Sash: The framework which holds the glass in a window or door

Sash Muntin: One of the rabbeted bars into which glass is fitted in a sash containing two or more

lights

SC: Door opening size designation, denoting "single car"

Scarf Joint: Method of joining pieces of lumber together by gluing and pinning with wood dowels

Scribing: Cutting a door bottom rail to match the contour of the floor

Scutcheon: See Escutcheon

Section: Garage door component that extends the full width of an opening; usually joined together

by hinges

Section Joint Meeting Rail Seal: A weather seal between door sections **Section Joint Meeting Rail Type Seal:** See Section Joint Meeting Rail Seal



Seattle - Spokane - Salt Lake - San Diego

Sectional Door: See Sectional-Type Door

Sectional-Type Door: Door made of two or more horizontal sections hinged

together so as to provide a door capable of closing the entire opening and which is by means of

tracks and track rollers

Servicing: See Maintenance

SG: Refers to "single glazed"

Shaft Bearing: A bearing that is used to maintain torsion shaft alignment and reduce friction

Sheave: A metal or plastic pulley that is designed to guide the cables employed in a counterbalance

system

Sheave Fork: A yoke type device used to attach the sheave to extension springs

Shiplap Section Joint: Section joint interface that steps up from one level to a second level from the

front of the door to the back of the door

Shoe Molding: See Quarter Round

S-Hook: Hardware device used to connect an extension spring to a pulley. These are also used with

other door related hardware (i.e. chain on locks)

Shop Drawings: Drawings provided by the manufacturer or door supplier to the architect-engineer

showing the plans, sections, elevations, and details of the work required, submitted to assure

proper interpretation of the intent of the architectural drawings

Side Bearing Plate: See End Bearing Plate

Side Seal: See Stop Mould

Sideroom: A horizontal measurement from each side of the door opening, outward to the nearest obstruction **Single Door:** Commonly used to refer to smaller width doors used on one car openings

Single Strength Glass: See Single Thick Glass

Single Thick Glass: A type of sheet glass used in glazing sashes

Slant: The pitch of a roof

Smile: See Bow

Snap Latch: See Automatic Latch **Solar Glass:** A type of tinted glass

Solid Rail: A rail made with one continuous piece of lumber without finger joints

Special Door: Non-standard door which must be custom manufactured and/or specified **Specifications:** A detailed statement of the quantity and type of material to be used in the

construction of a garage door system

Splice Plate: Plate used for attachment of track at the junction of tracks in clip type angle mounted

track

Spring Anchor: See Center Bearing Bracket

Spring Anchor Bracket: See Center Bearing Bracket

Spring Anchor Cone: See Stationary Cone

Spring Anchor Plate: See Center Bearing Bracket **Spring Assembly:** See Torsion Spring Assembly

Spring Assembly Closed Wound: A coiled torsion spring with no gaps between the coils **Spring Assembly Open Wound:** A coiled torsion spring with equal gaps between each coil **Spring Balance:** The amount of turns needed to counterbalance the weight of the garage door



Seattle - Spokane - Salt Lake - San Diego

Spring Bumper: Spring mechanism mounted on horizontal track that eases the door to stop in its upward travel to reduce shock and prevent pull down

rope breakage. Can be made from leaf springs or tension rods.

Spring Constant: Mathematically developed number from basic spring wire formulas, that applies to any specific wire size and coil diameter combination; used to determine the number of active coils a spring must contain

Spring Containment Device: See Containment Cable

Spring Fitting: A plug or cone used to adapt the torsion springs to the torsion shaft and/or center

bearing bracket. One piece is a stationary cone while the other fitting is a winding plug

Spring Hook: See S-Hook

Spring Latch Lock: See Automatic Latch

Spring Pad: Pad installed on header above the door to anchor the center bearing bracket. Can be

mounted in various locations, not necessarily in center, depending on size of springs

Spring Plug: See Spring Fitting
Spring Retainer: See Spring Fitting
Spring Winding Cone: See Winding Plug

Square Key: See Key

Standard Headroom: See Headroom **Standard Sideroom:** See Sideroom

Stationary Bearing Retainer: See Stationary Cone

Stationary Cone: Part that fits into the end of a torsion spring permitting the spring to be fixed to

the center bearing bracket. May also incorporate a retainer for a ball bearing or bushing

Stationary Plug: See Stationary Cone Stationary Sleeve: See Stationary Cone Stationary Spring Cone: See Stationary Cone

Steel Jamb: Door framing made from either channel or angle iron

Steel Jamb Mounted: A track system intended for mounting to a steel jamb

Steel Pin: Short, headless pointed nail driven through the dowel and rail in doors for greater

security

Step Down Plate: A means of closing a sectional door the last few inches of its travel **Step/Lift Plate:** A part that can be used as a step down plate and a lift handle for manually

operating a sectional door

Sticker: See Decal

Stile: Vertical reinforcement member of a section

Stile-and-Rail Garage Door: A sectional garage door featuring sections each made up of horizontal rail and vertical stile structural framing members that support panels connected to such members.

Stock Door: Door made to standard size and generally kept in inventory at either distributor or

factory warehouse **Stop:** See Stop Mould

Stop Mould: Serves to seal the perimeter of the door against weather and light infiltration; usually

nailed to the jamb, outside the door **Stop Moulding:** See Stop Mould



Seattle - Spokane - Salt Lake - San Diego

Stress: The amount of work required of a spring at a desired cycle level

Stretch Spring: See Extension Spring

Striker: See Striker Plate

Striker Plate: A plate used in conjunction with a locking system to secure a lock mechanism

Strut: Support stiffener to reduce deflection of the door sections in the horizontal position. Also, to

increase windload capability of a door

Sway Brace: See Angle Brace **Sway Strap:** See Angle Brace

Sweep: See Trajectory

Swing-Away Post: A type of removable center post that remains attached at the top and can be

pivoted out of the way

Swing-Up Post: See Swing-Away Post **T Handle:** A handle in the shape of a "T"

T Lock Handle: See T Handle

Tapered Vertical Track: See Inclined Track

TC: A designation of door opening size indicating an opening for two cars

Template: A pattern used as guide to shape something or show hole drilling locations. Also a short

header to support a beam in a wall **Test Load:** See Test Wind Load

Test Wind Load: Specified difference in static air pressure (positive or negative), equal to a specified

percentage greater than or equal to 100% of the design load

Thermal Barrier: See Thermal Break

Thermal Break: The separation between the outer and inner surfaces of a door section

Thermal Seal: See Bottom Weatherseal

Tin-Canning: See Oil-Canning

Tog-L-Loc: Method of mechanically securing two pieces of steel together without welding, riveting or bolting

Tongue and Groove Section Joint: Section joint interface commonly composed of a middle protrusion on a garage door section edge mating with a middle groove on an abutting section edge **Tongue and Groove Board:** Vertical wood planks that when laid out side-by-side resembles wainscoting.

Top Carrier: See Top Fixture

Top Fixture: A bracket for positioning the top guide roller on the top section of a door

Top Header Seal: See Top Seal

Top Rail: Horizontal rail forming the top of a door as distinguished from the meeting rails and

bottom rail

Top Roller Bracket: See Top Fixture **Top Roller Fixture:** See Top Fixture

Top Seal: Weatherstripping which fastens to the top of the door to seal the door along the top of

the opening

Torque: The twisting force around an axis



Seattle - Spokane - Salt Lake - San Diego

Torque Bar: See Torsion Shaft

Torsion: Act of twisting or turning of a torsion spring by the exertion of forces tending to turn one end about a longitudinal axis while the other end is held stationary

Torsion Bar: A long metal bar that transfers torque from a spring to a winding plug

Torsion Shaft: A shaft that transfers torque from springs to load

Torsion Spring: A spring that works in the manner of twisting one end or part about a longitudinal

axis while the other end is held or turned in the opposite direction developing torque **Torsion Spring Assembly:** Hardware used to make up door counterbalance assembly

Torsion Spring Counterbalance Assembly: See Torsion Spring Assembly

Torsion Tube: See Torsion Shaft **Torsion Tube Coupler:** See Coupler

Track: Channel shaped metal bars or rails in which upward acting doors operate via track rollers **Track Bracket:** A fixture, connected to a track, which is designed for the track to be mounted to the

jamb

Track Clip: A metal plate used to attach tract to wall angle

Track Graduation: The differential distance from the track to the door jamb, measured at the top

and bottom of the vertical track

Track Guard: Added protection for back of vertical track recommended in cases where powered

material handling fork trucks and similar equipment may be operating in the area.

Track Hanger Kit: See Back Hang
Track Radius: See Horizontal Radius

Track Roller: Roller assembly for guiding the door sections along track

Trajectory: The arc of travel or sweep of the top section as the door is raised from closed to open

position

Translucent Door: Door that allows the passage of light without being transparent

Transom Bar: A horizontal crossbar in a window, over a door, or between a door and a window or

fanlight

Transom Section: An extra section above a garage door opening sometimes used to allow extra lift

of the horizontal tracks to accommodate a trolley type operator

Trim: The finishing materials; such as the lock and handles on the door

Triplex Spring: Three springs of increasing diameter assembled one inside another using special

spring fittings

Trolley Opener: See Drawbar Operator

Trolley Type Operator: See Drawbar Operator

True Divided Lite: A window composed of several smaller windows separated from each other by

window mullions
Truss: See Strut
Truss Bar: See Strut

Tubular Shaft: A hollow shaft

Turn: A 360-degree revolution of a component about its axis

Turns On Spring: See Winds On Spring

Twist: A form of warp caused by the twisting or winding of the edges of a rail



Seattle - Spokane - Salt Lake - San Diego

U-Bar: See Strut

U-Bar Stiffener: See Strut

U-Bar Truss: See Strut

Urethane (Finish): A clear finish commonly used as a top layer to finish wood

Urethane (Insulation): See Polyurethane

"U" Strut: See Strut

U-Value: Thermal transmission coefficient which is a measurement of heat, in BTU's, transmitted through one square foot of material (the door) in one hour at a temperature difference of 1 degree

from one side to the other

Upper Trajectory: See Trajectory

Upper Vertical Track: Upper track assembly on a vertical lift door

Varnish: Glossy clear top coat used on finished wood; may not be suitable for outdoor wood

applications for its lack of breathability

Vent: An opening located in the bottom section of a door for ventilation

Vertical Grain: See Edge Grain

Vertical Lift: Refers to a hardware design that causes doors to open vertically where no horizontal

tracks are required

Vertical Lift Drum: A cable drum with changing radius grooves to negate spring tension

Vertical Post: A vertical reinforcement sometimes installed for high wind events

Vertical Splice Angle: See Jamb Angle

Vertical Track: The portion of track that is oriented vertically and is adjacent to the jamb

Vertical Track Assembly: An assembly made up of a piece of vertical track and a piece of continuous

angle or jamb brackets used to secure the track to the jamb.

Vision Lite: Glazing that is mounted in a door

Warning Tag: A tag with warnings and/or instructions for safe operation **Water Seal:** A coating of some kind used to prevent the absorption of water

Water Stop: See Rain Stop
Weatherseal: See Weatherstrip

Weatherstrip: Material used at the perimeter of a garage door, or between joints of a garage door,

intended to improve a door's performance against air infiltration and thermal transmission

Wedge Connection: A device composed of a steel wedge and clip for securing the joint between

vertical and horizontal track sections

West Coast Lumber: Lumber produced on the West Coast, generally used in manufacturing wood

sectional garage doors

Wheel and Axle: See Track Roller Wicket Door: See Pass Door

Wind Load: See Design Wind Load Winding Bar: See Winding Rod

Winding Cone: Part that fits into a torsion spring permitting winding and tension adjustment

Winding Cone Set Screw: See Winding Plug Set Screw

Winding Cone Socket Head Set Screw: See Winding Plug Set Screw

Winding Plug: See Winding Cone



Seattle - Spokane - Salt Lake - San Diego

Winding Plug Set Screw: Set screw fasteners used to lock the winding plug to the torsion shaft

Winding Rod: A solid rod that fits into the socket of the winding plug to tension torsion springs

Winding Sleeve: See Winding Plug Window Lite: See Vision Lite

Winds On Spring: The number of winding turns on a torsion spring

Wire Glass: Glass into which wire netting is woven prevent splintering from heat or impact

Wire Rope: See Aircraft-Type Cable

Wire Size: The diameter of the wire in a spring

Wood Anchor Pad: See Spring Pad Wood Casing: See Wood Jamb

Wood Grain: Direction or orientation of the wood, as seen in a piece of lumber

Wood Jamb: Upright wood piece forming the side of an opening

Wood Jamb Mounted: Refers to mounting vertical track to wood jambs

Woodruff Key: Special half-moon shaped steel key

High Performance Door Terminology

Activation Device: Any device used to initiate operation.

Astragal: A compressible or deformable seal provided on the leading edge of the door.

Authority Having Jurisdiction (AHJ): The organization, office, or individual responsible for approving

equipment, an installation, or a procedure.

Backing Plates: See Crush Plates

Backup Electric Operation: See Emergency Electric Operation

Barrel Assembly: A cylindrical horizontal member at the head of the opening that supports the door

curtain.

Bellmouth: Flared upper portion of guides to ease entry of curtain into the guides.

Bottom Bar: A reinforcing member at the lower edge of the door curtain assembly. It shall be provided

with an astragal or sensing edge. **Bottom Beam: See Bottom Bar**

Bottom Edge: A compressible or deformable seal provided on the leading edge of the door.

Between Jamb Mounted: Type of mounting where the guides are positioned between the mounting surfaces and not on the surface (interior or exterior) of the wall.

Brackets: Plates bolted to the wall or to extensions of the guide wall angles that serve to support the barrel and form end closures for the hood.

Brush Seals: Term used to refer generically to the use of brush filament material as a weather-seal.

Brush Weather-stripping: Weather-stripping for use on all configurations of doors to close the gaps at jambs and header.

Chain Hoist: A mechanical device to assist in raising and lowering the door by use of hand chain.

Closed Position: A position of the door curtain with the underside of the bottom bar, including an astragal or sensing edge in contact with the sill along the entire width of the opening.

Control Panel: An enclosure that houses electrical controls.

www.GarageDoorSaltLake.com www.GarageDoorSpokane.com www.GarageDoorsSanDiego.net



Seattle - Spokane - Salt Lake - San Diego

Counterbalancing: A method by which the hanging weight of the door curtain is balanced by springs or weights.

Counterweights: See Counterbalancing

Crush Plates: Bearing plates provided where doors are mounted on wall units with hollow cells to accommodate through-wall bolts to prevent crushing of the hollow wall.

Curtain: Industrial fabric door panel or slats assembled together to close off the door opening.

Curtain Slats: Formed or extruded members that form the door curtain.

Cycle: An action on the door from the fully closed position, to the fully open position, and returned to the fully closed position or reverses to the fully open position.

Door Opening: The clear open width and height.

Door Panel: See Curtain

Drive Shaft: The shaft in the barrel that is securely attached to the barrel, through welding or pinning. When this shaft rotates the barrel should also rotate.

Drive System: See Operator. **Drum Tube: See Barrel Assembly**

"E" Guides: - Common expression for the shape that guides form when they are mounted to steel jamb

supports or frames.

Electric Sensor Edge: See Sensing Edge

Electromechanical Release: A device that holds the automatic closing device until it is released upon receipt of a signal from a detection system.

Emergency Electric Operation: Any door with a motor operator and an Uninterruptible Power Supply (UPS) capable of opening and/or closing the door while facility line power is off.

Emergency Release Device: Permits emergency manual operation of the door without electrical power to open.

Endlock: A component that is attached to curtain to prevent curtain from shifting laterally.

Exterior Hood: A protective covering for a barrel assembly.

Exterior Mounted: Condition where door is mounted on exterior surface exposed to weather and wind load.

Fabric Clear Area: Minimum distance between any obstructions required to prevent fabric wear. **Face of Wall Mounting:** Door mounting where guides mount directly to wall, and side and header clearances are allowed.

Fascia: Metal closure for the back of door housing.

Guide Block: Component used to guide door travel in guide rail.

Guide Rail: See Side Frame. Gussets: Support brackets.

Hand of Operation: The side on which the door operator is placed, as viewed from the barrel side of the door. It is either a RH or LH operation.

Headerbox: A mechanical box at the head of the door, containing a drive system.

Headplates: See Brackets.

Header Seal: Weather-stripping mounted to opening header to seal the opening between header and curtain

Headroom: Amount of clear unobstructed space above the door lintel or header.

High Performance Door: Rolling, folding or sliding non-residential door, generally characterized by either higher cycles or higher speeds, typically made-to-order, and designed for higher or special types of durability.



Seattle - Spokane - Salt Lake - San Diego

Hood: A housing that mounts horizontally, serving as an enclosure for the door header.

Inertia Brake: A unit that is attached to the door shaft and headplate or wall, which will stop the door from free falling should there be a failure in the motor operator brake, roller chain drive or torsion spring assembly. When the shaft is moving at a certain RPM the unit will lock up the shaft, preventing it from moving until door can be repaired.

Intermediate Beam: Beam contained in door curtain to increase wind load resistance.

Jamb: The vertical member that frames the side of an opening in the wall.

Jamb Angle: See Wall Angle

Jamb Load: Force exerted on jamb by guide assembly when curtain is subjected to wind load.

Leading Edge: The front edge of the door relative to its closing movement. **Lintel:** A horizontal member spanning and carrying the load above an opening.

Manual Override: Means of operating a door by manual operation in case of power loss.

Manual Release Device: Device that allows manual operation of the door without electric power to

open.

Motor Cover: Cover to protect the motor from exterior weather, debris, or to meet OSHA safety

requirements.

Motor Shroud: See Motor Cover

Mullion, Swing-Up: A combined guide assembly joining two adjacent doors where center guide is hinged and motorized to lift up and out of the way, to expose a full opening width when both doors are open. **Mullion, Removable:** A combined guide assembly joining two adjacent doors, grilles or shutters where

center guide is removable to expose a full opening width.

Operator: A powered mechanism that opens and closes a door.

Panel: Assembly that closes off the door opening.

Perforated Slats: A curtain with holes or slots in slats to allow air infiltration.

Photoelectric Sensor: A sensor that consists of a light-emitting device and a light-receiving device. If the beam of light is blocked by an obstruction, the sensor signals the operator to stop and/or reverse.

Photoelectric Eye: See Photoelectric Sensor

Pipe Shaft: See Barrel Assembly Reversing Edge: See Sensing Edge

Roll Cover: See Hood

Roll Tube: See Barrel Assembly

Safety Arrestor: A device to support door if lifting member fails. **Self Support Header:** Head support member supported by jambs.

Sensing Edge: A device added to the leading edge of a power operated door, which stops or reverses the

door curtain or panel upon contact with an obstruction when closing under power.

Sensing Edge, Pneumatic: An air hose installed inside the astragal and connected to a diaphragm switch, to signal the operator to stop or stop-and-reverse the door.

Sensing Edge, Electric: An electrical astragal enclosed with two parallel foils. When bottom of closing door touches an obstruction, the foils close an electric circuit to signal the operator to stop or stop-and-reverse the door.

Sensing Edge, Optical Type: Astragal enclosing a tube with a light emitting transmitter at one end and a detector at the other end. When IR source is obstructed, the operator will stop or stop-and-reverse the door.



Seattle - Spokane - Salt Lake - San Diego

Side Frame: Vertical assembly, fastened to the jamb, in which the curtain travels and which retains the

edges of the door curtain and closes the space between the curtain edges and the jamb.

Side Jamb: See Wall Angle

Sideroom: Required unobstructed space on either side of the opening.

Shroud: Cover or hood at side frame and header.

Slats: See Curtain Slats

Slide Bolt: Locking device on bottom bar or edge of door, which slides into guide and is equipped for

padlocking. Mounted either inside, outside or on both sides of the door.

Sloped Bottom Bar: Tapered leading edge to match sloped sill of opening, and will hang into opening on low side unless door height is increased and door curtain is raised to have sloped bottom edge clear

opening when door is open.

Spring Cycle Life: Spring counterbalance is designed for a fixed number of cycles.

Spring Counterbalance: See Counterbalancing

Stop Edge: See Sensing Edge

Stops: Bars mounted at top of guides to prevent bottom bar from traveling out of the guides when the

curtain is fully raised.

Thru-Wall Operation: A door driven by means of a hand chain, crank or motor operator located on the

opposite side of the wall.

Torsion Spring: A spring in a counterbalance assembly, used to counterbalance the curtain.

Vision Panel: Cutout in a door, glazed with clear plastic or glass.

Wall Angle: An angle of the guide assembly, which attaches to the face of wall and supports the load of

the door assembly.

Wind Bar: Channel, bar, tube or other material used to stiffen the door panel under wind load.

Windlock: A component attached to prevent the curtain from leaving the guides under wind load or a

component used to prevent a door from lifting upward under wind load.

"Z" Guides: Common expression for the shape that guides form when they are mounted to masonry

jambs.



Seattle - Spokane - Salt Lake - San Diego

Angle Mounted Track: A method of fastening vertical track to a doorjamb using a full height continuous angle. (Commercial garage door application)

Anodize An electrolytic method of coating aluminum with a protective or decorative film, which is generally clear in color.

ASHRAE Acronym for American Society of Heating, Refrigeration, and Air Conditioning Engineers.

Astragal: Weather-stripping added to bottom section of the garage door to seal the opening along the floor.

Back Hangs The vertical supports for the horizontal track, cross-braced to prevent lateral movement and track spread.

Backroom The required clearance from the face of the header to any obstruction to the rear of the horizontal track.

Bead A metal, vinyl or rubber strip used to secure glass around the periphery of a pane. (Commercial garage door application)

Bottom Bracket A structural support located on the bottom section of the garage door that provides for attachment of the lifting cables on the sectional garage doors. Also referred to as "Bottom Corner Bracket." (Note: Track rollers may have a separate door attachment in some garage door designs.)

Bracket Mounted Track A method of fastening vertical track to a doorjamb using angle brackets. Also referred to as "Mounted or Track Bracket."

Break-Away Track Vertical track assembly that steps back from the jamb used for high lift and vertical lift track to permit outside lock handle projection to clear the lintel. (Commercial garage door application)

Bumpers, Spring A leaf spring installed at the end of the horizontal track. Especially useful on lift clearance or full vertical manually operated garage doors, acting as a cushion and stop. (Commercial garage door application)

Cable Drums Grooved drums on the torsion spring shaft that lifting cables wind around when the garage door opens. Designed to allow cable to be accumulated or dispensed in an orderly manner and to prevent lapping or cable chafing.

Cable Safety Device A safety bottom fixture specifically designed to prevent a garage door from falling if a cable breaks.

Cable Sleeve A manufactured device used to form a loop of cable, the size of which is determined by the cable diameter.

Cable Stop A swagged fitting at the end of the cable to prevent slippage through a slot in a drum. **Cables** Multistrand wire used to attach the garage door, via bottom brackets, to the counterbalance mechanism.

Carry-Away Post See "Removable Post." (Commercial garage door application)

Center Bearing Plate See "Center Support Bearing."

Center Hinge Flat hinge located on all intermediate stiles to allow for garage door sections to turn the track radius as the door opens.

Center Lift Cable Additional cable assembly, which is secured to the outside of the garage door at points toward the center of the door. Used to provide extra lifting support for extremely wide or heavy doors. (Commercial garage door application)

Center Post See "Mullion." (Commercial garage door application)



Seattle - Spokane - Salt Lake - San Diego

Center Stile/Mutt Vertical members of a garage door section that provide structural rigidity and location for center hinge attachment. (Commercial garage door application)

Center Support Bearing Bearing and mounting plate installed at approximately half the door width above the garage door, which acts as a support for the spring shaft. Can be mounted in various locations, not necessarily in the center, depending on size of the springs.

Chain Hoist Adds mechanical advantage to manually-operated garage doors. Couples to one end of the solid torsion shaft. (Commercial garage door application)

Clearances The amount of sideroom, headroom, and backroom required to properly install a sectional garage door.

Coupling Adjustable two-part cast iron connector for torsion solid shafts on wide garage doors. Eases installation and allows adjustment in cable lengths so that doors will operate smoothly without cocking. **Curtain** The part of the sheet door that actually rolls up and down or slides side to side. Manufactured of corrugated sheets seamed together.

Cycle One complete cycle of begins with the garage door in the closed position. The door is then opened and closed again. Note: Torsion spring operated garage doors with higher-than-normal cycle life requirements may be specified with 25,000, 50,000, or 100,000 cycle springs.

Dead Load A static-applied load. A load without movement.

Door Frame The frame into which the garage door fits, consisting of a door header and two upright members called doorjambs.

Door Size Always specify the width first and the height second: for instance 8' 6" (2591 mm) wide by 7' 3" (2210 mm) high. Refer to "Opening Size."

Double-Thick Glass Lighter than plate glass, about 1/8" (3.18 mm) thick, often termed double-strength glass. See "Glass Type."

Drums Circular stamped metal parts attached at various locations along the tubular shaft that allows the sheet door curtain to coil up when the garage door opens.

Duplex Spring A combination of two torsion springs.

End Stiles Stile located at each end of a garage door section that provides for attachment of end hinges. **Escutcheon** A plate surrounding the lock mechanism that acts as a bearing surface for the lock shaft; one of the parts of a lock set, usually held in place by small screws known as escutcheon screws.

Exhaust Ports Orifices put in the bottom section of a garage door for release of carbon monoxide fumes when tubed from an automobile exhaust system. (Commercial garage door application)

Extension Springs Counterbalance springs that provide lifting force by stretching. Commonly called stretch springs. Extension springs are mounted to each of the rear track hangers and attached to a pulley at the other end of the spring.

Exterior Lock Keyed lock that can be operated on exterior of the garage door.

Extrusion Fabricated aluminum or plastic shapes made by forcing hot aluminum or plastic billets through an extrusion press die.

Flag Bracket L-shaped bracket used to facilitate the union between vertical and horizontal tracks. **Flush Design** Refers to garage door sections unbroken by roll-formed ribs. The face of the complete garage door presents an even surface.

Follow-the-Roof Track Designed to place the back track on the roof incline, and as close as practical to the roof. Can be used with standard lift or lift clearance track. (Commercial garage door application)



Seattle - Spokane - Salt Lake - San Diego

Front-Mounted Low Headroom Low headroom hardware where springs mount on torsion shaft above opening. (Commercial garage door application)

Full Vertical Track Assembly An assembly designed from a piece of vertical track and a piece of continuous angle or jamb brackets. Used to secure the track to the jamb. (Commercial garage door application)

Full Vision Section A totally glazed section with various types of glass or clear plastic. The section is formed of aluminum extrusions that combine with steel sections above and below. See "Glass Type." (Commercial garage door application)

Galvanizing Zinc coating to protect steel against corrosion.

Glass, Insulated Two pieces of glass spaced approximately 1/4" (12.7 mm) apart and hermetically sealed to form a single-glazed unit with an air space between. Heat transmission through this type of glass can be as low as half that of non-insulated glass.

Glass, Tempered Reheated to just below the melting point and suddenly cooled. When shattered it breaks into small pieces. (Commercial garage door application)

Glass, Wire Polished or rough glass, 1/4" (6.35 mm) thick. Wire mesh is embedded within the glass so that the glass will not shatter when broken. Many types of wire patterns are available. (Commercial garage door application)

Glazed, Glazing Section windows or lites in place of a steel or aluminum panel. See "Glass Type." **Headplate** Structural bracket used to secure vertical and horizontal track, as well as counterbalance systems.

Headroom A measurement from the top of the garage door opening upward to the lowest building obstruction on the inside of the header wall. Use this measurement for vertical clearance all the way back to the end of the horizontal track.

High Cycle Springs Special counterbalance springs with increased life cycle capability for high usage garage doors.

High-Lift See "Lift Clearance." (Commercial garage door application.)

Hinges To make the independent sections to act as a complete garage door, the sections must be hinged together. Hinges are found on the end stiles and center stiles at the meeting rails. All hinges perform two basic functions within a garage door system: 1. They join the sections together with bolts or screws. 2. They allow the sections to break, independent of each other, as the garage door travels up and down. Hinges on the end stiles perform two additional tasks: 1. They are designed to support the roller on which the garage door travels. 2. They are offset to provide a flush fit to the garage door itself when in the closed position.

Horizontal Track An assembly usually made up of a section of track and reinforced with an angle that is used to both guide and support the garage door in the horizontal position. Furnished with an integral section of curved track. See "Radius."

Incline To slope, to slant. To follow roof pitch. (Commercial garage door application)

Inclined Track Tapered vertical track and a graduated height of edge hinges that assure a weather tight fit between the garage door and jamb.

Inside Lock Spring loaded, sliding deadbolt lock operable only from the interior of the garage door. **Insulation**Material that has the ability to reduce heat or cold transmission.

Insulation Terms:

BTU Amount of heat necessary to raise the temperature of one pound of water, one degree Fahrenheit.



Seattle - Spokane - Salt Lake - San Diego

K-value (Thermal Conductivity) Laboratory-determined value of the thermal conductance of a material. **R-value** (Thermal Resistance) Ability of a material to retard the transmission of heat. The higher the R-value, the better the garage door insulation performance.

U-Factor (Heat Transmission Coefficient) Amount of heat, in BTU, transmitted through one square foot of material (the garage door) in one hour at a temperature difference of 1° Fahrenheit from one side to the other. The lower the U-value, the better the insulating material.

Jambs Seal Weather-stripping attached to the garage door jamb to provide a seal along the jambs. Jambs The upright framing on each side of the garage door opening. When wood jambs are specified, the vertical track is mounted to the inside surface of the jamb and the stop molding is nailed to the side surface within the opening. For steel garage door jambs, see "Reverse Angle Mounting." For wood or masonry jambs, see "Bracket Mounted Track" and "Angle Mounted Track."

Lift Clearance Refers to track hardware that causes the garage door to rise vertically some distance before leveling out into a horizontal position. Also known as "High Lift Track," Lift-Clearance is the distance above the top of the garage door opening to the underside of horizontal tracks.

Lift-Handle A handle, normally on the bottom section of the garage door, to assist in manually lifting the sectional door.

Lites Frames glazed with glass or clear plastic. The number of panels in a section limits the quantity of lites that can be installed. May be double glazed for insulation value. See "Full Vision Section."

Low Headroom Track hardware accessories to improve garage door installation with minimum headroom conditions.

Master Keying Arrangements whereby cylinder locks, although fitted with different keyed cylinders, can be opened or locked by one master key. In new buildings, the hardware supplier has responsibility for the lock cylinder and the locking device has to be coordinated with the hardware supplier. Cylinder may be furnished by this supplier and changed in the field. (Commercial garage door application)

Meeting Rail The top or bottom horizontal rail in any section that meets and joins with an adjacent garage door section in horizontal rail.

Mounting Plates Flat steel or wood members placed on the wall to accommodate spring support, spring shaft bearings, chain hoists and mountings for operators.

Movable Center Post A lightweight extruded aluminum post/track assembly, which substitutes for the jamb between two adjacent garage doors and can be released and carried from the opening. (Commercial garage door application)

Mullion A slender dividing bar between two garage doors. Usually designed to carry horizontal (wind) load but not vertical load. (Commercial garage door application)

Muntin A bar member supporting and separating panes of glass within a sash or door.

NEMA National Electrical Manufacturers Association. Established to provide standards for electrical components. Number designation refers to motor operator and controls to meet the ambient requirements.

Opening Size Frequently called daylight opening or finished opening. Dimensions are taken between masonry or wood walls or between steel jambs.

Opening Width Distance between jambs of the garage door opening.

Outside Hook-up Bottom fixture with an arm that bends around vertical track to receive lifting cables. Generally used with low headroom hardware.



Seattle - Spokane - Salt Lake - San Diego

Padding Refers to the wood framing at jambs and header to which the garage door track is mounted. Usually furnished by general contractor. See "Jambs."

Pane The area between vertical stiles in a garage door section.

Pass Door Sometimes called wicket door or access door. It is a small swing door built into the larger upward acting garage door allowing people to walk in and out without opening the large door. Cannot be used as a legal exit. (Commercial garage door application)

Pedestrian Door Access door adjacent to the upward acting garage doors. Avoids the use of a sectional door as a legal egress. (Commercial garage door application)

Perimeter Seal Complete weather-stripping package for sectional garage doors, consisting of astragral, jamb seal and header seal.

Perimeter Wearstrip Vinyl or felt attached to corrugated sheet door curtain to prevent rubbing. Located at the ends or drum locations.

Rabbeted Joint Joint formed by connecting rails with grooves cut out in opposing edges to permit overlapping weather tight meeting of sections. See "Shiplap Joint" and "Tongue-and-Groove."

Radius The curved portion of the track, which allows the door to move from vertical to horizontal (and vice versa). The curve is measured in inches, thus determining headroom requirements. See "Headroom."

Rain or Water Stop A step at the edge of the garage floor, approximately 1" (25.4 mm) higher than the outside finish. The garage door sits between the two.

Rear Track Hangers Often constructed of punched angle iron, laterally braced, these hangers attach the end of the horizontal track to the garage ceiling. See "Back Hangs."

Removable Post Designed to allow the use of two or more garage doors in a single opening with center posts that can be removed when doors are raised. Especially desirable where small openings are required normally, but occasionally the entire clear opening is necessary. (Commercial garage door application)

Reverse Angle Mounting An exceptionally sturdy method of track mounting used on all steel jambs and wood jambs at the architect's direction. See "Angle Mounted Track." (Commercial garage door application)

Roller Assembly The combination of a wheel and axle that is used to guide a garage door through the track system, either 2" (50.8 mm) or 3" (76.2 mm) diameter, depending on track size. Available as short or long stem.

Rollers Steel, ball-bearing wheels or nylon rollers that allow sections to roll freely along garage door tracks.

RSLO/LSLO Right side looking out/left side looking out. Used to indicate hand of chain hoist or electric operation or lite or exhaust port location. (Commercial garage door application)

Safety Spring Containment An extra cable used with garage door extension springs to prevent it from causing damage or injury if the spring breaks. The cable is threaded through the center of the spring and is secured on both ends of the horizontal track.

Sectional Joint Meeting Rail Seal An integral weather-strip with the section at the joints between garage door sections.



Seattle - Spokane - Salt Lake - San Diego

Sectional Garage Doors Garage doors made of two or more horizontal sections hinged together to provide a door large enough to close the entire opening. Sectional doors are guided into the horizontal or open position by a system of vertical or horizontal tracks. May be fabricated of continuous roll-formed steel with reinforcing ribs or flush sections of steel or aluminum.

Shaft Bearings Type of bearing that adequately supports the radial forces dictated by the weight of the counterbalance assembly and door weight, and the lateral forces exerted. See "Center Support Bearing." **Shafts, Tubular and Solid** A tubular or solid steel counterbalance shaft transmits the lifting force of the torsion springs to the cable drums and lifting cables.

Sheave A pulley with integral ball bearings designed to handle a cable. Used to control the movements of the cables employed in the garage door counterbalance system. Various types are stud or clevis. **Shiplap Joint** The configuration of the meeting rails. When closed, the shiplap prevents rain, wind, and

light from infiltrating the garage door between the door sections. See "Tongue-and-Groove."

Sideroom A horizontal measurement from each side of the garage door opening outward along the wall to the nearest obstruction within the building.

Spring Anchor Plates Designed to transmit torque from the stationary end of a torsion spring to the building structure and, at the same time, support the weight of the torsion shaft in a level attitude. The anchor plate is able to withstand the lateral forces exerted by a torsion spring. Usually supplied by the general contractor. See "Center Support Bearing."

Spring Assembly Hardware used to make up the garage door counterbalance assembly.

Spring Bumper Small spring-cushioning bumper attached to the horizontal track, which stops the door at the full open position. (Commercial garage door application)

Spring Fittings The sleeves or cones that are used to affix the torsion springs to the torsion shaft. One piece is a stationary sleeve or spring retainer, and the second piece is an adjusting cone or winding sleeve.

Steel Jamb Mounting Continuous angle attached to vertical track and fastened to the jamb by welding, self-tappers, or bolts. (Commercial garage door application)

Steel Jambs Door framing made from either channel or angle iron.

Stop Molding Seals the perimeter of the garage door against weather and light infiltration. Stop molding is nailed to the jamb, outside the door, and is incorporated as one of the final steps in the installation process. Sometimes called doorstop, it is usually wooden or plastic.

Stop Bars Bars or brackets mounted at the top of guides to prevent bottom bar from traveling out of the guides when the sheet door curtain is fully raised. (Commercial door application)

Straight Incline Track Vertical track assembly that extends from floor to twice the height of the opening without break-away feature. See "Break-Away Track." (Commercial garage door application)

Struts L-shaped metal reinforcement members attached horizontally to the inside of the garage door section to add strength and rigidity. Struts are necessary on wide heavy garage doors to help prevent sagging and bowing and to provide additional reinforcement to comply with the required windloading. Also called trusses.

Swing-Up Post See "Removable Post."

Tongue-and-Groove The configuration of the meeting rails that differs from shiplap in having matching channel groove and protrusion on the longitudinal edges of the abutting meeting rails for wind and weather protection.



Seattle - Spokane - Salt Lake - San Diego

Top Fixture Adjustable brackets that carry track rollers mounted on the top corners of the garage door's top section.

Top Header Seal Flat weatherstrip fastened along the full width of top door section as a seal along the header.

Top Rail The horizontal rail forming the top horizontal member of a garage door as distinguished from the meeting rails and bottom rail.

Top Seal Weatherstripping that fastens to the top of the garage door generating a seal along the top of the opening.

Torque The turning effect of a tangential force acting at a distance from the axis of rotation or twist; torsion springs apply such effect to spring shafts.

Torsion Shaft The shaft of a torsion spring assembly that transmits the lifting force of the torsion springs to cable drums and lifting cables.

Torsion Spring Counterbalance Assembly Designed and constructed to provide a safe and durable conversion of spring torque to lifting force by balancing the weight of a sectional overhead garage door. **Torsion Springs** Mounts above the garage door opening. The springs are manually wound, or charged, then set to a shaft that runs through the spring. The spring turns the shaft, which raises or lowers the door via the cables winding on drums.

Track Provides a guide for the roller wheels. The vertical track is mounted to the jambs with brackets on each side of the garage door opening. The horizontal track contains a curved end called the radius (See "Radius"). In the closed position, the garage doors rest in the vertical track. In the open position, the garage doors suspend from the horizontal track. Sectional door track usually consists of two vertical pieces and two horizontal pieces.

Trajectory The arc of travel, or sweep of the top section, as the garage door is raised from closed to open position. Determining the trajectory is important when planning the location of pipes, light fixtures, etc.

Vertical Lift A hardware design that allows a sectional garage door to open vertically along the wall above the door opening without turning back inside the building. (Commercial garage door application) **Wicket Door** Hollow-metal pedestrian door installed adjacent to the sheet door that shares the same building opening. (Commercial garage door application)

Winding Bars Used by garage door installers to set initial tension on torsion springs at the winding cones.

Winding Cone Part that fits into a torsion spring, permitting winding of the torsion spring and tension adjustment.

Winding Sleeves Designed to safely allow the application of torque from a torsion spring. The winding sleeves' design properly retains a torsion spring when fully wound or unwound and withstands the radial and lateral forces exerted by the torsion spring.

Windload The lateral force that the wind exerts upon a garage door as it stands in a closed position. **Mounted** Regular method of mounting vertical track to wood jambs.

Wood Jambs Upright wooden piece forming the side of the garage door opening.